

**Restore DRAGON™ M standard configuration**




**Set DLL6000-R compatibility**



**Restore DLL6000-R default**



**Enter configuration**



**Gun Address Stamping disabled**



**Cradle Address Stamping disabled**



**Gun Address Delimiter disabled**



**Cradle Address Delimiter disabled**



(Suite)

**Set Gun Address**



**Numéro de pistolet**  
3 chiffres (voir annexe 1)

beeper off



RADIO TIMEOUT



**Numéros 0 0 0**  
(voir annexe 1)

backlight on



timeout



**Numéros 3 et 1**  
(voir annexe 1)

Clear display after decode



EAN 128



**Exit and Save configuration**



MAITRE	ESCLAVE
<p><b>Bind</b></p>	<p><b>Join</b></p>

**Insérez le pistolet dans la base**

- Enter configuration
- Gun Address Stamping enabled
- Exit & Save configuration

# Annexe 1

## HEX / NUMERIC TABLE



0



2



4



6



8



A



C



E



1



3



5



7



9



B



D



F

Backspace



Cancels an incomplete configuration sequence