



*Set All Default*



*Scan Suffix*



*1*



*0*



*1*



*3*



*Scan Options*



*<DATA> <SUFFIX>*



*Enter*



*Standard RS-232C*