



FICHE PARAMETRAGE Scanner SYMBOL LS2208 Configuration globale (USB)

PARAMETRAGE DU SCANNER



Set All Defaults



Scan Suffix



1



0



1



3




Scan Options



<DATA> <SUFFIX>



Cancel



*Enable Interleaved 2 of 5



I 2 of 5 - Two Discrete Lengths



2



0



2



4



Enter



Simple COM Port Emulation

USB