

Enter configuration



---

BEEPER INTENSITY

beeper off



low intensity



medium intensity



high intensity



---

BEEPER TONE

tone 1



tone 2



tone 3



tone 4



---

Exit & Save configuration

